




## Low Expansion Foam Sprinkler Type: SB-SU 1/2" / SC-SU 3/4"



### Technical Specs

Spray characteristics  
Responsivity

Spray-Sprinkler SU, upright  
Quick- Response RTI- 035 **(F3)**  
Standard- Response RTI- 105 **(G5)**

Max. working pressure  
Min. working pressure  
Temperature range  
K- Factor

12.5 bar  
0.35 bar  
57°C, 68°C, 79°C, 93°C, 141°C, 182°C, 260°C (G5 only)  
**SB-SU** K80, K115  
**SC-SP** K160, K200

Protection area K80  
Protection area K115  
Protection area K160  
Protection area K200  
Foam expansion rate  
Foam agent

Max. 12.25 m<sup>2</sup>  
Max 9 m<sup>2</sup>  
Max 9 m<sup>2</sup>  
Max 9 m<sup>2</sup>  
app. 6-Times (Depending on foaming agent, K-factor and pressure)  
All firefighting foam agents of Dr.Sthamer, other foam concentrates on request

### Material / Coatings

Sprinkler body /Deflector  
Foaming creator  
Button  
Sealing Assembly  
Bulb  
Pins

Brass or stainless steel  
Stainless steel  
Brass or stainless steel  
Stainless steel / Teflon  
Borosilikatglass  
Stainless steel

**General Instructions**

Do not install any bulb type sprinkler if the bulb is cracked or there is a loss of liquid from the bulb. With the sprinkler held horizontally, a small air bubble should be present. The diameter of the air bubble is approximately 1,6mm for the 57° to 2,4mm for the 182° temperature ratings. A leak-tight ¾ " NPT sprinkler joint should be obtained by applying a minimum to maximum torque of 10 to 14 Nm. Higher levels of torque may distort the sprinkler inlet and cause leakage or impairment of the sprinkler.

**Installation Instruction**

- Sprinkler shall only installed by trained personal.
- Install sprinklers only with the special wrench foreseen for each sprinkler type.
- Install sprinklers only in fully installed and fixed pipe work.
- The threads (fitting / socket) must be clean, free of grease and burrs.

**Never** install a sprinkler that has had their packaging damaged.

**Never** install a sprinkler that has been dropped or has suffered any impact.

**Always** to align sprinklers turn clockwise only. Alignment on the opposite side can create leakage.

**Warning**

- Sprinklers containing the original packing have been manufactured and tested according to the requirements of the sprinkler authorities.
- Any modification to the sprinkler in the form of painting, wrap of deflector, will seriously affect the operation. This will lead to withdraw of insurances approval and any guarantee of EuroSprinkler AG
- Sprinklers (brass and chrome plated) may only install in normal atmosphere. For areas with aggressive, corrosive atmosphere use sprinklers with special coating or stainless steel sprinklers.

**Foam Sprinkler marking**

RTI- value	<b>Q</b> = RTI < 30
Week of manufacturing	<b>35</b> = Week 35
Year of manufacturing	<b>09</b> = Year 2009
Temperature range	57°C, <b>68°C</b> , 79°C, 93°C, 141°C, 182°C
Sprinkler size	¾"
K- Factor	K200
Certificated at	<b>VdS</b>

